Model S Do It Yourself Search Adding and Removing Keys

To add a new key card or key fob:



- 1. On the touch screen, touch Controls > Locks > Keys > Add Key.
- Scan your new key card or key fob on the card reader located on the wireless phone charger. To scan the key fob:
 Place it at the top of the left phone charger, against the center divider.
 Point the front of the key fob down.
 Swipe downwards (as shown in the image).

When you hear a chime and the new key is recognized, remove it from the card reader.



- Scan a key card or key fob that has already been paired to the vehicle to confirm new key pairing.
 When complete, the key list includes the new key. Touch the associated pencil icon to customize the name of the key. Removing a key:

When you no longer want a key to access Model S (for example, you lost your phone or key card, etc.), follow these steps to remove it.

- On the touchscreen, touch Controls > Locks.
 In the key list, find the key that you would like to delete and touch its associated trash icon.
 When prompted, scan an authenticated key card or key fob on the card reader to confirm the deletion. When complete, the key list no longer includes the deleted key.

Model S requires at least one authenticated key card or key fob at all times. If only one key card remains on the key list, you cannot delete it.



Do It Yourself General Information Restarting and Powercycling

Connecting and Pairing

Adding and Removing Keys Connecting to Wi-Fi Pairing a Bluetooth Phone

Programming HomeLink

Replacing the Key Fob Battery Unlocking and Starting Using Mobile App Wheels, Tires, and Brakes

Wipers and Washers

Climate Components Front and Rear Trunk

Calibrate Cameras

Low Voltage Battery

Charging © Tesla 2022